



TILE PR 120

Ceramic Primer

Description

TILE PR 120 is an acrylic polymer based primer suitable for adhering ceramics on ceramic floors. It is used to reduce the absorbency of the surface.

Fields of Application

It can be suitable to increase adherence on ceramic, glassy, mosaic or wooden surfaces.

Features and Benefits

- Excellent adhesion performance.
- Easy to use.
- Prevents rapid water loss of the mortar before cement and gypsum based coating applications.
- Non odour. Safely use in indoor.
- Resistant to moisture.
- Provides waterproofing.

Technical Data

Content	Acrylic Resin
Thinning	Ready to use
Application Tools	Brush / Roller
Drying Time	
Waiting period between the coats	1 hours
Last coat	3 hours
GTIP No	3208.90.91.00.23

Application Procedure

Preparation of Substrate

Application surfaces should be clean off the rust, dirt and moisture. Surface should be clean and dry.

Floor Systems

TILE PR 120

Ceramic Primer

Application Method

Before the application product should be mixed 3-5 minutes until homogenous mixture obtained. Product is ready to use. Does not diluted.

Consumption

1,0 kg material primed 6-8 m² area.

Packaging

20 kg plastic bucket

Shelf Life

12 months in original, unopened package.

Storage

Store in dry area between +5°C and +35°C. Protect from heat, freezing and direct sunlight.

Cleanup Information

Clean tools and equipment with industrial type solvents immediately after use. Dried material can only be removed mechanically.

Cautions / Limitations

- Does not provide waterproofing by itself.
- It may be harmful with skin contact.
- Do not apply in freezing conditions or during precipitation.
- Protect applied materials from rain, freezing, foot traffic and continuous high humidity until completely dry.
- Do not use when air and surface temperatures are below +3°C and above +35°C.

Health and Safety

TILE PR 120

Ceramic Primer

Warning! Cause eye and skin irritation. If eye or skin contact, get immediate medical attention. If swallowed, do not induce vomiting. Call a physician or poison control center. Never give anything by mouth to an unconscious person.

Wash hands thoroughly after handling. Wear protective clothing, gloves, eye and face protection. Do not eat, drink or smoke when using this product. Take off contaminated clothing and wash it before reuse. Dispose of unused, contents, container and other contaminated wastes in accordance with local, state, federal and provincial regulations.

Keep container closed when not in use. Keep out of the reach of children.

Limited Warranty: This product is subject to a written limited warranty which can be obtained free of charge from BAUMERK Company. Please contact with technical service department for further information and support.

Tel: +90 212 438 7 888 Fax: +90 212 438 67 05